

# OW-50000 User Manual

This equipment is for household use, and may be placed on a table or mounted onto the wall. If necessary, a hose may be connected. Caution: Do not bend the hose if used.

## Table of Contents





- I. Working principle
- II. Buttons on the display panel and control panel
- III. Basic operation procedures of buttons on the control panel
- IV. Equipment cleaning
- V. After-sales services
- VI. Precautions

### I. Working principle

The equipment has an advanced atomizing system integrating the world-leading cold air diffusing technology, through which essential oil is atomized into nano molecules and diffused into the air, in realization of lasting fragrance in the air. The technology is currently the only diffusing technology in the world that can maintain the integrity of essential oil. Nano particles formed through atomization by using the technology may diffuse faster and stay longer with the optimal natural quality of essential oil retained, so that use of essential oil can be more economical and effective. Therefore, it is the best choice to improve the environment and create atmosphere for hotel halls, conference rooms, multi-functional halls, shopping malls, real estate companies, automobile exhibition halls, music halls, photographic studios, art galleries and other indoor spaces.

### II. Buttons on the display panel and control panel

#### **Press DOWN&UP at same time to unlock the screen**

1.  SET: For setting time, day of a week, duration of essential oil spray, lasting period of fragrance and suspension of essential oil spray. All these settings can be done with the button.
2.  DOWN: For slight down-regulation of time, essential oil spray period and date.
3.  UP: For slight up-regulation of time, essential oil spray period and date.
4.  CONFIRM: When all settings are done, press this button for confirmation and the screen will return to the work interface. Hold this button down for 4s, the screen will flash black and factory setting will be restored.
5. Time interface: The system time is displayed in the 24-hour format. Beijing time can be set by holding down this button for 4s, specifically: hold down the Set button until the indicator flickers, and then press UP or DOWN to change the time.
6. Week-day interface: There are three options, i.e. Monday-Sunday, Monday-Saturday, and Monday-Friday. Hold down the Set button until corresponding indicator flickers, and then press UP or DOWN to change option.
7. Time period: Hold down the Set button until time periods No. 1, 2, 3 are displayed. Three time periods are available for selection for this machine. For each time period, a different concentration of fragrance can be set. "M" represents minute; "S" represents second.
8. ON: 1/2/3 + ON: Hold down this button until 1+ON is displayed; set the start time point of the first time period and duration of continuous essential oil spray in the first time period. Set the same

for 2+ON and 3+ON.

9. OFF: 1/2/3 + OFF: Hold down this button until 1+OFF is displayed; set the ending time point of the first time period and suspension of continuous essential oil spray in the first time period. Set the same for 2+OFF and 3+OFF.

### III. Settings

#### a. Setting of the current time and week day:

Hold down the SET button for 4s

When it flickers, press UP or DOWN until it comes to the current week day

Press the SET button

When the hour indicator flickers, press UP or Down until it comes to the present hour

Press the SET button

When the minute indicator flickers, press UP or Down until it comes to the present minute

Press the SET button to complete setting

Tips: Fast adjustment can be realized by holding down UP or DOWN.

#### b. Setting of on/off time and duration of on/off interval

Press the SET button

At this time a week day flickers. Press UP or Down to adjust the weekday option. The timer is only set within the weekday combination

Press the SET button

When the hour indicator for ON flickers, press UP or DOWN to the hour when the machine is expected to be turned on

Press the SET button

When the minute indicator for ON flickers, press UP or DOWN to the minute when the machine is expected to be turned on

Press the SET button

When the hour indicator for OFF flickers, press UP or DOWN to the hour when the machine is expected to be turned off

Press the SET button

When the minute indicator for OFF flickers, press UP or DOWN to the minute when the machine is expected to be turned off

Press the SET button

When the minute indicator for work duration flickers, press UP or DOWN to the duration in minute as needed

短按设置键

Press the SET button

工作时长秒闪烁,按UP、  
DOWN键调整至所需  
要的时长

When the second indicator for work duration flickers, press UP or DOWN to the duration in second as needed

短按设置键

Press the SET button

间歇时长分闪烁,按UP、  
DOWN键调整至所需  
要的时长

When the minute indicator for interval flickers, press UP or DOWN to the duration in minute as needed

短按设置键

Press the SET button

间歇时秒闪烁,按UP、  
DOWN键调整至所需  
要的时长

When the second indicator for interval flickers, press UP or DOWN to the duration in second as needed

如果要进入第二组的设置，  
继续按设置键；如果不需要  
继续设置，则按确认键，  
设备按设定的时间和时长  
开始工作。

To continue setting of the second group, press SET again; if not, press CONFIRM, and the equipment will work based on the set time and duration.

小提示:  
按UP或DOWN键调节  
各组的开机时间至--:  
--，可以关闭改组的  
工作设置。（仍然保  
留了同时按加减键快  
速关闭当前组）

Tips: Press UP or DOWN to change the starting time of a group to --: --, so as to close the work setting of the group. (The current group can be closed by simultaneously pressing UP and DOWN)

## 四、设备清洗

- (1) 按照精油瓶更换的方式,取出精油瓶.
- (2) 将少量酒精装入精油瓶进行清洗.
- (3) 精油瓶清洗完毕后,装入新的酒精,并将精油瓶装入设备,开启电源,雾化5-10分钟.
- (4) 设备清洗完毕,关闭电源,取出精油瓶.
- (5) 装入新的精油瓶,以待下次使用.

## 五、售后服务

本产品自售出之日起,一年内免费保修,超出免费保修期实行有偿维修,终身保养。

### IV. Equipment cleaning

- (1) Take out the essential oil bottle following the procedure for replacement of the essential oil bottle.
- (2) Fill a small amount of essential oil into the essential oil bottle for cleaning.
- (3) After cleaning of the bottle, fill unused alcohol into the bottle, and install the bottle onto the equipment; turn on the power for 5 to 10 minutes' atomization.
- (4) When equipment cleaning is done, turn off the power and take out the essential oil bottle.
- (5) Install a new essential oil bottle for future use.

### V. After-sales services

This product is subject to one-year warranty as of the selling date. Any repair or maintenance after the warranty period may be performed on a paid basis. Life-long service is available for the product.

## 六、注意事项

- (1) 当设备中带有精油瓶时,请勿倒置,避免精油泄露。
- (2) 请勿使用过载电源插座、电源线以及破损的电源插头,以免引起火灾,造成危险。
- (3) 请勿用水清洗设备以及精油瓶,以免损坏雾化系统。
- (4) 若有任何技术问题,请直接与厂家联系。
- (5) 进行设定时,停止时间必须大于起始时间,若设定停止时间小于起始时间,则系统会强制修正。
- (6) 在每次更换精油时,需先用酒精喷洗喷头3-5分钟,清洗完成后再装上时间,则系统会强制修正。

### VI. Precautions

- (1) When the equipment carries an essential oil bottle, it shall not be inverted, so as to prevent leakage of essential oil.
- (2) It is forbidden to use any overloaded power socket, power cord or damaged power plug, so as to prevent fire risks.

- (3) Do not clean the equipment or the essential oil bottle with water; or otherwise damage may be incurred to the atomization system.
- (4) If you have any technical problem, please contact the manufacturer directly.
- (5) Upon setting, the stop time shall be longer than the start time; or otherwise if the stop time is shorter than the start time, the system will automatically correct it.
- (6) Upon replacement of essential oil, it is required to clean the spray nozzle with alcohol for 3-5 minutes; when it is reinstalled after cleaning, the system will automatically correct the time.